


## RCA WebOS TV Initial Setup Guide

After you have initially connected your TV antenna or cable, turn the television ON. A screen will display asking you to select Language and Location. NB: for location, the Television is preset to USA – If you are in the USA **enter your ZIP Code**.


If you are located outside of the USA, leave the country set to USA and enter the following ZIP CODE **12345**.

Complete the initial setup.

To change your country setting (if you not located in USA) – go to Main Menu **“General”** (The Wrench Symbol):




Choose **Location**:




### Set your Services Country:

Select your country (in the menu) to enable the applicable WebOS Apps and features for your country.

If you choose “Set Automatically”, the operating system of your television will detect your location (country) from your internet connection.



### Set the current Date, Time & Time Zone:



Setting the correct Date, Time & Time Zone ensures that all of the smart features of your RCA WebOS TV function properly.